# EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM

### **INSPECTION**


EC09L-01

## 1. VISUALLY INSPECT LINES AND CONNECTIONS

Look for loosen connections, sharp bends or damage.


#### 2. VISUALLY INSPECT FUEL TANK

Look for deformation, cracks or fuel leakage.



#### 3. VISUALLY INSPECT FUEL TANK CAP


Check if the cap and/or gasket are deformed or damaged. If necessary, repair or replace the cap.



#### 4. REMOVE CHARCOAL CANISTER


#### 5. VISUALLY INSPECT CHARCOAL CANISTER

Look for cracks or damage.




# 6. CHECK FOR CLOGGED FILTER, AND STUCK CHECK VALVE

(a) Using low pressure compressed air (4.71 kPa (48 gf/cm², 0.68 psi)), when port B closed, blow into port A and check that air flows from the port C.



- (b) Apply vacuum (1.96 kPa (20 gf/cm², 0.28 psi)) to port A, check that the vacuum does not decrease when port B and C are closed, and check that the vacuum decreases when port C is released.
- (c) Apply vacuum (9.32 kPa (51 gf/cm², 1.37 psi)) to port B, check that the vacuum does not decrease when port A and C are closed, and check that the vacuum decreases when port C is released.

If a problem is found, replace the charcoal canister.



#### 7. CLEAN FILTER IN CANISTER

Clean the filter by blowing 294 kPa (3 kgf/cm<sup>2</sup>, 43 psi) of compressed air into port B while holding port A closed.

#### **NOTICE:**

- Do not attempt to wash the canister.
- No activated carbon should come out.
- 8. REINSTALL CHARCOAL CANISTER